






PowerFlex 4/40/400 Input RFI Filters
PowerFlex 4/40/400 HF-EingangsfILTER
Filtres d'entr ee RFI PowerFlex 4/40/400
Filtro di Ingresso RFI - PowerFlex 4/40/400
Filtros de entrada RFI PowerFlex 4/40/400
Input RFI Filters PowerFlex 4/40/400
Filtros RFI de Entrada PowerFlex 4/40/400

Installation Instructions
Installationsanleitung
Installation
Installazione
Instalaci n
Instructies
Instala o



Wait three minutes for capacitors to discharge to safe voltage levels.

Drei Minuten warten, bis die Kondensatoren sich auf eine sichere Spannung entladen haben.

Attendre trois minutes pour s'assurer que les condensateurs se sont d echarg s jusqu'   des niveaux de tension sans danger.



Attendere tre minuti affin ch  i condensatori si scarichino fino a raggiungere un livello di tensione sicuro.

Espre tres minutos a que los condensadores se descarquen a niveles seguros de tensi n; de lo contrario puede sufrir lesiones o incluso la muerte.

Wacht drie minuten zodat de condensators zich kunnen ontladen tot een veilig niveau.

Espre tr s minutos para que os capacitores descarquem a n veis seguros de tens o.

3



www.abpowerflex.com



www.rockwellautomation.com

Corporate Headquarters
Rockwell Automation, 777 East Wisconsin Avenue, Suite 1400, Milwaukee, WI, 53202-5302 USA, Tel: (1) 414.212.5200, Fax: (1) 414.212.5201

Headquarters for Allen-Bradley Products, Rockwell Software Products and Global Manufacturing Solutions
Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
Europe/Middle East/Africa: Rockwell Automation SA/NV, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Headquarters for Dodge and Reliance Electric Products
Americas: Rockwell Automation, 6040 Ponders Court, Greenville, SC 29615-4617 USA, Tel: (1) 864.297.4800, Fax: (1) 864.281.2433
Europe/Middle East/Africa: Rockwell Automation, Herman-Heinrich-Gossen-Strasse 3, 50858 Köln, Germany, Tel: 49 (0) 2234 379410, Fax: 49 (0) 2234 3794164
Asia Pacific: Rockwell Automation, 55 Newton Road, #11-01/02 Revenue House, Singapore 307987, Tel: (65) 6356-9077, Fax: (65) 6356-9011

U.S. Allen-Bradley Drives Technical Support
Tel: (1) 262.512.8176, Fax: (1) 262.512.2222, Email: support@drives.ra.rockwell.com, Online: www.ab.com/support/abdrives

Publication 22-IN001D-MU-P – May 2005
Supersedes Publication 22-IN001C-MU-P – September 2004

